CARD READER

**C**nnectland

USER'S Manual

7 M2

5 XD

6 MICRO SD

1 USB 2.0

4 CF/MD

2 SD & MMC

## **Feature**

## Hardware Introduction

- 1. USB port for plugging into any USB device
- 2. Slot for SD, MMC and RS-MMC cards
- Slot for Memory Stick, Memory Stick PRO, Memory Stick Duo and Memory Stick PRO Duo cards• Fully compliant with USB 2.0
- 4. Slot for Compact Flash cards and MicroDrive
- 5. Slot for Smart Media cards
- 6. Slot for MICRO SD
- 7. Slot for M2 8. LED indicator
- -Red (Access LED) :

there will two situation with RED LED

- \* The RED LED will be on when the memory card is inserted
- \* The RED LED will be flashing when the memory card is accessed.
- -Green:
- \* When the card reader is connected successfully, the Green LED will be on

## **Package**

- Card Reader
- Manual
- Screws

# System Requirement

- 1. Available on-board USB 1.1 or USB 2.0 port on the motherboard
- 2. Support Windows 95/98/98SE/2000/ME/XP/VISTA/WINDOWS 7;Mac system 8.6, 9.x, 10.1x or 10.2x or above; Linux kernel versions 2.4 x or above

CARD READER

USER'S Manual

## Installation

## Hardware Installation

Before starting to install the card reader, please make sure the operating system for your computer is installed completely.

- 1. Shut down the computer before installing the card reader.
- 2. Remove the computer case cover and locate an empty 3.5" floppy drive bay.
- 3. Insert the card reader into the empty 3.5" floppy drive bay and fasten it with the screws.
- 4. Connect the USB2.0 cable from the card reader to your motherboard.

### NOTE:

- Please refer to your motherboard manual for the USB header pin assignment information. The USB cable is consist of Red, White, Green and Black wires. Each of them shall be connected to a specific pin to the USB header of the motherboard.
- Do not take out the memory card or the USB device connected to the card reader when the Access LED is flashing. Otherwise, the data will be lost.

## Software Installation

This card reader is Plug and Play under Windows 2000,XP or Vista,there is no driver required. If your operating system is Windows 95,98,or 98SE please download the driver from www.connectland.com.hk.